



**MONTANA**

Department of Transportation

April 2025

MDT Civil 3D State Kit -  
Auto Attach XREF

YOUTUBE VIDEO DOCUMENTATION

# TABLE OF CONTENTS

<b>Table of Contents</b> .....	<b>2</b>
<b>Overview</b> .....	<b>3</b>
<b>Companion Documentation</b> .....	<b>3</b>
Using the Command.....	3

## OVERVIEW

The **Auto Attach Xref** command simplifies the placement of drawing references by making it a one step process. **Auto Attach Xref** will place a DWG file as a reference, at the coordinates 0,0,0, as an overlay, with a relative path, on a new unique layer. The layer name takes the form: X-XREF-*filename*

The **Auto Attach Xref** command is developed and provided by MDT.

## COMPANION DOCUMENTATION

YouTube Video Link: <https://youtu.be/tPmlSBFaqUY?si=qC9ropP4F64XvwLi>

## USING THE COMMAND

1. Type **MDTATTXREF** at the command line or press the **Auto Attach Xref** ribbon button.
2. Select a drawing file
  - a. Browse to a DWG file and click “Open”.
3. The drawing will be referenced into the current drawing at 0,0,0, as an overlay, with a relative path, on a new unique layer.