



February
2025

MDT Civil 3D State Kit -
Align North Arrow

YOUTUBE VIDEO DOCUMENTATION

TABLE OF CONTENTS

Table of Contents.....	2
Overview	3
Companion Documentation	3
Using the Command.....	3

OVERVIEW

The **Align North Arrow** command rotates a north arrow block in a paper space layout to align with the direction of north in a viewport that has a rotated model space view.

The **Align North Arrow** command is developed and provided by MDT.

COMPANION DOCUMENTATION

YouTube Video Link:

https://www.youtube.com/watch?v=7KvKC1AB_L0&list=PLxseor6l1x1GY4KNF_93eyCRSVeO61OwX&index=4

USING THE COMMAND

1. Type **MDTRN** at the command line or press the **Align North Arrow** ribbon button.
2. Select a Viewport.
3. Select North Arrow block.
4. The north arrow block will be aligned to the view of the viewport.