

April 2025

MDT Civil 3D State Kit - Station Increment Labels

YOUTUBE VIDEO DOCUMENTATION

TABLE OF CONTENTS

Table of Contents	2
Overview	3
Companion Documentation	3
Using the Command	3

OVERVIEW

The **Station Increment Labels** command will place Alignment - Station/Offset labels based on an increment of an alignment along offset object(s) relative to the alignment.

The **Station Increment Labels** command is developed and provided by WisDOT.

COMPANION DOCUMENTATION

YouTube Video Link: https://youtu.be/amR2s1I-ATw?si=jpsGsiGOqOz8VSMe

USING THE COMMAND

Prerequisite: An Alignment - Station/Offset label of the desired style must be placed in the drawing prior to running the command.

- 1. Type **MDTCreateStaIncLabels** at the command line or press the **Station Increment Labels** ribbon button.
- 2. Select an Alignment Station/Offset label to be used as the style template.
- 3. Select an Alignment to be the baseline.
- 4. Enter a station increment value and press **<enter>**. (The default is 25.)
- 5. Select object(s) to be labeled.
- 6. Pick start station.
- 7. Pick end station.

Labels will be placed at the start and end station and at each increment based on the absolute increment value of the baseline alignment. (Not relative to the beginning of the object(s) selected.)